


Prehľad vybavenia pre kapacitné priváranie svorníkov

Zváracie zdroje pre kapacitné priváranie svorníkov 

Pístole a príslušenstvo pre kapacitné priváranie



	BMS-6 ISO	BMS-8 N	BMS-8NV	BMS-9	BMS-9V	BMS-10N	BMS-10NV	BMS-10P
PS-OK	M3 - M6	M3 - M8	M3 - M8	M3 - M8 *1	M3 - M8 *1	M3 - M8	M3 - M8	M3 - M8
PS-1	M3 - M6	M3 - M8	M3 - M8	---	---	M3 - M8	M3 - M8	M3 - M8
PS-1K	M3 - M6	M3 - M8	M3 - M8	M3 - M8 *1	M3 - M8 *1	M3 - M8	M3 - M8	M3 - M8
PS-1KI	Tellerstift Cupped head pin	M3 - M8	M3 - M8	---	---	---	---	---
PS-3K	M3 - M6	M3 - M8	M3 - M8	M3 - M8 *1	M3 - M8 *1	M3 - M8	M3 - M8	M3 - M8
PS-3K Statív	M3 - M6	M3 - M8	M3 - M10	M3 - M8 *1	M3 - M10 *1	M3 - M8	M3 - M12	M3 - M8
PS-9	---	---	---	M3 - M8	M3 - M8	---	---	---
PS-9K	---	---	---	M3 - M8	M3 - M8	---	---	---
PS-2KS	---	---	---	M3 - M8	M3 - M8	---	---	---
PS-3	---	---	---	M3 - M8 *1	M3 - M8 *1	M3 - M8	M3 - M8	M3 - M8
PS-3A*	---	---	---	---	---	M3 - M8	M3 - M8	M3 - M8
PS-6A*	---	---	---	---	---	M3 - M8	M3 - M8	M3 - M8
SK-1A*	---	---	---	---	---	M3 - M8	M3 - M8	M3 - M8
SK-5AN*	---	---	---	---	---	M3 - M8	M3 - M8	M3 - M8
SK-5AP*	---	---	---	---	---	M3 - M8	M3 - M8	M3 - M8
SK-1 T-Nut	M3 - M6	M3 - M8	M3 - M8	M3 - M8 *1	M3 - M8 *1	M3 - M8	M3 - M8	M3 - M8
SK-5 T-Nut	---	---	---	M3 - M8 *1	M3 - M8 *1	M3 - M8	M3 - M8	M3 - M8
PTS-2*	---	---	---	---	---	M3 - M8	M3 - M8	M3 - M8
* Vhodné iba pre zváracie zdroje vybavené automatickým podávaním.		Štandard			*1 - je možné pri použití adaptéra			